


OPERATION PARAMETERS DIAGRAM



NOTES:
 1. The last 3 characters depend on the type of alarm configured
 2. Absolute setpoint limits are set in configuration.

Shaded boxes are only visible when FULL access level is chosen
 No need to change
 Cannot be changed